

Service Manual

CAR STEREO CX-5000EN

CAR STEREO CASSETTE TAPE PLAYER with AUTOMATIC EJECT



SPECIFICATIONS*

Type:	4-track, 2-program stereo system
Tape Speed:	4.75 cps
Frequency Response:	50 ~ 10,000 Hz
Power Output:	
Continuous:	2 x 4.0 W (at 10% THD)
Maximum:	2 x 5.0 W (Volume and Tone Controls at max.)
(Conditions; at 400 Hz, 4 Ω load, 13.2 V DC)	
Power Supply Voltage:	DC 12 V (11 V ~ 16 V), Negative ground
Power Consumption:	Approx. 8 W (0.6 A at 0.5 W output, DC 13.2 V)
Speaker Impedance:	4 ~ 8 Ω
Wow & Flutter:	0.3%
Crosstalk:	35 dB
Signal to Noise Ratio:	40 dB
Stereo Separation:	25 dB (at 400 Hz)
IC's:	3
Diode:	1
Dimensions:	Width: 140 mm Height: 50 mm Depth: 173 mm
Weight:	1.25 kg

FEATURES

- 4-track, 2-program automatic eject cassette car stereo tape player.
- DC 12 V, Negative ground.
- Stereophonic reproduction.
- Fast Forward/Fast Rewinding.
- Automatic eject at tape end.
- Underdash installation.

* Chromium-dioxide tape and C-120 tape are not recommended to use.


* Weight and Dimensions shown are approximate.

* Specifications subject to change without notice.

CONTENTS


	Page
DIMENSIONS AND LOCATION OF CONTROLS	1
FUSE REPLACEMENT	1
NORMAL CARE AND MAINTENANCE	1
PARTS LOCATION	2
IC EQUIVALENT CIRCUIT	3
INSTALLATION INSTRUCTIONS	3
SCHEMATIC DIAGRAM	4
WIRING DIAGRAM	5
AUTOMATIC EJECT SYSTEM	6
EXPLODED VIEW (UNIT)	8
EXPLODED VIEW (TAPE PLAYER)	9
REPLACEMENT PARTS LIST	7, 10 ~ 12
TROUBLE SHOOTING GUIDE	13

DIMENSIONS AND LOCATION OF CONTROLS



FUSE REPLACEMENT

Be sure to use a 3 A fuse for replacement. Use of a larger fuse may not protect the circuit in the unit of excessive current drain.



NORMAL CARE AND MAINTENANCE


■ Tape Player Maintenance

After many hours of operation, it is advisable to clean the oxide residue from the tape head and pinch roller ass'y to obtain superior performance from the player. Oxide accumulated on the tape head and pinch roller ass'y may cause tape hiss and malfunction.

The more often the player is operated, the more often it should be cleaned.


■ Cleaning Tape Head

To clean the tape head, open the upper cover and clean the residue from the head with a cotton swab dampened with isopropyl (rubbing) alcohol.



■ Cleaning Pinch Roller


To clean the pinch roller, turn the motor until it operates by lifting up the DC motor. Clean the pinch roller with a cotton swab dampened with alcohol.



■ Head Azimuth Adjustment

Head azimuth adjustment can be made by removing the upper cover.


Playback a standard test tape or recorded music tape and turn the head adjustment screw for maximum loudness.




PARTS LOCATION

- Numbers in () are indicated in the REPLACEMENT PARTS LIST.
- Refer to EXPLODED VIEWS in pages 8, 9

TOP VIEW, WITH COVER REMOVED





BOTTOM VIEW, WITH COVER REMOVED





IC EQUIVALENT CIRCUIT


- YEAMM5152L (IC200), PRE AMP




- YEAMUPC1155H (IC201, 301), POWER AMP



INSTALLATION INSTRUCTIONS



SCHEMATIC DIAGRAM MODEL CX-5000EN



Power Output:
2 x 4.0 w (at 10% THD)
Speaker Impedance:
4 ~ 8 Ω


NOTES:

- 1) Voltage are those measured when there are no signal with a power supply voltage of 13.2 V DC.
 - 2) Voltage should be measured with a VOM whose internal resistance value is 20 k-ohm/volt.
 - 3) Measurement base: ⊖LINE
- Exact value determined by production process. This schematic diagram is the latest at the time of printing and subject to change without notice. Replace same value as original parts.
 - The shaded area on this schematic diagram incorporates special features important for SAFETY. When servicing it is essential that only manufacturer's specified parts be used for the critical components in the shaded areas of the schematic.

R	200	202	201	203	204	700	205
	300	302	301	303	304		305
C	200	201	202	203	204	701	205
	300	301	302	303	304		305



CASSETTE CAR STEREO

MODEL CX-5000EN




AUTOMATIC EJECT SYSTEM


PLAYING





AUTOMATIC EJECT



MANUAL EJECT



EJECTED



Replacement Parts List Model NO. CX-5000EN


NOTES:
1. Be sure to make your orders of replacement parts according to this list.
2. Components identified by shaded area have special characteristics important for safety. When replacing any of these components, use only manufacturer's specified parts.
3. The column of Ref. No. indicates the located position of the parts on the EXPLODED VIEW, and see the cross section of the horizontal column (1 ~ up) and the vertical column (A ~ up).

Ref. No.	Part No.	Part Name & Description	Pcs Set	Remarks
MISCELLANEOUS				
F (3-4-E)	XBBTC30NR1	Fuse, 3A	2	
M101 (4-E)	YEAJ01186	Power Supply Cord (Blue)	1	
M102 (3-E)	YEAJ01187	Power Supply Cord (Red)	1	
M103 (4-E)	YEAJ03189	Speaker Cord (R) (Blue Stripe)	1	
M104 (4-E)	YEAJ03190	Speaker Cord (L) (Red Stripe)	1	
M105 (4-E)	YEAJ01089	Power Supply Cord (Blue)	1	
M106 (3-E)	YEAJ01142	Power Supply Cord (Red)	1	
M107 (1-A)	YEF013049	Eject Button	1	
M108 (1-A)	YEF07068	Knob, Tone Control, & Volume Control	2	
M109 (1-A)	YEF04014	Knob, Balance Control	1	
M110 (2-A)	YFC02387	Escutcheon Ass'y	1	
M110-1 (2-B)	YEFX002077	Cassette Door	1	
M110-2 (2-A)	YEPW06120	Shaft for Cassette Door	1	
M110-3 (2-B)	YAFX011301	Spring for Cassette Door	1	
M110-4 (1-C)	YEF04052	Cushion Rubber	1	
M110-5 (2-B)	YEF01106	Pad	1	
M111 (3-D)	YEFM01335	Main Seal	1	
M112 (4-D)	YEF013076	Case	1	
M113 (2-E)	YEF01222	Chassis	1	
M114 (5-E)	YEF03247	Upper Cover	1	
M115 (1-C)	YEF05124	Bottom Cover	1	
M116 (2-E)	YAFX016027	Cord Clamp	1	
M117 (4-B)	YEF01150	Heat Sink	1	
M118 (4-C)	YEFX021486	Mounting Bracket	2	
M119	XYN3-C6FXS	⊕ Screw w/Washer, 3mmφ x 6mm	4	

Ref. No.	Part No.	Part Name & Description	Pcs Set	Remarks
M120	XWE3FX	Washer, Flat 3mmφ	4	
M121	YEJN01031FX	Nut, Hexagon	2	
M122	XYN2+C4FXS	⊕ Screw w/Washer, 2mmφ x 4mm	3	
M123	XYN3+F6FXS	⊕ Screw w/Washer, 3mmφ x 6mm	8	
M124	XSN2+3FXS	⊕ Screw w/Washer, 2mmφ x 3mm	2	
M125	XYN3+F6FZS	⊕ Screw w/Washer, 3mmφ x 6mm	6	
M126	XYN2+C5FXS	⊕ Screw w/Washer, 2mmφ x 5mm	1	
M127	XWA2BFX	Washer, Spring 2mmφ	2	
M128 (4-C)	EMCS0501	Connector Plug	1	
M129 (4-D)	EMCB0525A01	Connector Jack	1	
M130 (2-A)	YEFX999099	Space Cover (L)	1	
M131 (1-C)	YEFX999100	Space Cover (R)	1	
M132	XTB3 + 6FFXS	⊕ Screw, Tapdite, 3mmφ x 6mm	1	

EXPLODED VIEW (UNIT)

Numbers in ○ are indicated REF. NO. in the REPLACEMENT PARTS LIST.




EXPLODED VIEW (TAPE DECK)

■ Numbers in ○ are indicated REF. NO. in the REPLACEMENT PARTS LIST.

NOTE : The symbols next to the screws indicate as follows.

★	XYN3 + C6FXS	⊕ Screw w/Washer, 3mm φ × 6mm
□	XYN2 + C4FXS	⊕ Screw w/Washer, 2mm φ × 4mm
※	XYN3 + F6FXS	⊕ Screw w/Washer, 3mm φ × 6mm
⊗	XSN2 + 3FXS	⊕ Screw, Pan 2mm φ × 3mm
△	XYN3 + F6FZS	⊕ Screw w/Washer, 3mm φ × 6mm
□	XYN2 + C5FXS	⊕ Screw w/Washer, 2mm φ × 5mm
⊗	XTB3 + 6FFXS	⊕ Screw, Tapite 3mm φ × 6mm



[illegible]

Ref. No.	Part No.	Part Name & Description	Pcs Set	Remarks
VARIABLE RESISTORS				
VR200, 300	EVJR1AK15A54	50k OHM (A) x 2 Volume Control	1	
VR201, 301	EVJR0AK15A14	10k OHM (A) x 2 Tone Control	1	
VR202	EVAK0AC10G54	50k OHM (G) Balance Control	1	
COIL				
L700	YETO020F012	Choke Coil	1	
SWITCH				
SW700	YEAS23111	Power Switch	1	
ACCESSORIES				
A101	YEF02039	Mounting Bracket	1	
A102	YAFG04008	Supporting Strap	1	
A103	YEP9BS360	Mounting Screw Kit	1	
	(XVG5C8FZS)	(Bolt, Hexagon 5mmφ x 8mm)	(3)	
	(XVG6C20FZS)	(Bolt, Hexagon 6mmφ x 20mm)	(3)	
	(XNG6G6FZS)	(Nut, Hexagon 6mmφ)	(3)	
	(XWA5BFZ)	(Washer, Spring 5mmφ)	(3)	
	(XWG5FZ)	(Washer, Flat 5mmφ)	(2)	
	(XWA68FZ)	(Washer, Spring 6mmφ)	(3)	
	(YEJW02019FX)	(Washer, Flat)	(1)	
	(XWG6FZ)	(Washer, Flat 6mmφ)	(6)	
PRINTING				
A104	YEFM06526	Instruction Book	1	

TROUBLE SHOOTING GUIDE

SYMPTOM	CAUSE	REMEDY
No output when cassette tape is inserted.	Fuse, blown.	Replace a rated fuse (3 A).
	Play On/Off Switch, faulty.	Repair or replace.
	Connector, disconnected.	Repair or replace.
High distortion or dead one channel.	Head face, dirty.	Clean it.
	Power IC, faulty.	Check and replace.
	Amplifier, faulty.	Check and repair.
Low volume.	Volume, balance, tone, faulty.	Check and replace.
	Head face, dirty.	Clean it.
	Power IC, faulty.	Check and replace.
	Amplifier, faulty.	Check and repair.
Low speed.	Volume control, faulty.	Check and replace.
	Motor, faulty.	Replace it.
	Cassette tape, faulty.	Replace a new tape.
	Drive belt, faulty.	Replace it.
Wow & flutter.	Tape drive mechanism, faulty.	Check and repair.
	Drive belt, faulty.	Replace it.
	Flywheel, greasy.	Clean it.
	Motor pulley, greasy.	Clean it.
	Motor, faulty.	Replace it.
	Pinch roller, faulty.	Replace it.
Automatic eject does not operate.	Cassette tape, faulty.	Replace a new tape.
	Hook, faulty.	Replace it.
	Reel mounting plate ass'y, faulty.	Replace it.
FF or REW does not operate.	Eject mechanism and relative parts, faulty.	Check and replace. (Refer to the Automatic Eject System in page 6.)
	REW lever ass'y, faulty.	Replace it.
	FR switch lever ass'y, faulty.	Replace it.
	Flywheel, greasy.	Clean it.